

RC1 Cart Assembly



Assembling the cart should not require any tools and can be assembled in a matter of a few minutes.
Shown below is the parts that come in the kit.





Install the tall square tubing section into the main frame and secure with the cast wing bolts. Then slide the round axle through the tubing and install the wheels. Secure the wheels in place with the washer and cotter pin.

Slide the square tubing with feet from the bottom up and secure with wing bolts. Install the tubing with the T bar on top. Then slide the handle in to a convenient position and lock into place with the wing bolts. The handle is pulled out for moving around and the pushed in for storage. Be sure to install the straps to lock the RC1 down to the frame.



One important thing is to vent the bucket. Venting the bucket allows the air to escape the crusher without blowing dust out the seams and the top of the crusher. The dust can also shorten the life of the air cleaners and engine. The simplest remedy is to install Tubeseal2 rubber seals and slide in vacuum a hose or 2" PVC pipe to redirect the dust. If you use the tubeseal2 you need drill a 3" hole in the side of the bucket to insert the tubeseal2. It is also very important not to breathe the dust from any rock crusher. Always wear a safety dust mask and eye protection.

